

SWISH

(CONTROL PAD)



PREPARATION

Secure the control pad to the underside of the worktop.

INITIALISATION PROCESS

The initialisation process must be completed before the first use.

Press and hold ★ button & ⚙ button simultaneously.

Keep holding them down until the legs move down to the lowest position. Release buttons and initialisation is complete.

ADJUSTMENT SETTINGS

Raise Worktop: Lift the lever

Lower Worktop: Press the lever down

Release the lever when the desired height is reached

SET MEMORY *Up to two memory settings can be saved

Only two memory positions can be set. If a third memory position is set, the previous one will be cleared.

1. Raise worktop to your desired height using the lever.
2. Press ★ button for 3 seconds until digital display begins to flash, then release the button to save and complete.
To Move between memory settings lift/ press the lever until it stops, it will stop at the saved memory position.

DELETE MEMORY SETTINGS

Delete one memory setting: Raise or lower the desk until it stops at the memory preset you wish to delete, press the ★ button for 3 seconds until the digital display flashes, then press the ★ button again to confirm deletion.

Delete all memory positions: Press ★ button for 8 seconds until the digital display flashes and shows 'CLr' then release the ★ button to confirm deletion.

CENTIMETER FORMAT SETTING




- | | |
|--------------------------------------|---|
| 1. Click ⚙ button 6 times | The display shows "F01" function setting interface |
| 2. Lift the lever or press the lever | The display shows "F01" |
| 3. Touch ⚙ button for 3 seconds | The display shows the current height in (cm) format |
| 4. Release ⚙ button | The centimeters unit format setting is complete |

INCH FORMAT SETTING

- | | |
|--------------------------------------|---|
| 1. Click ⚙ button 6 times | The display shows "F01" function setting interface |
| 2. Lift the lever or press the lever | The display shows "F02" |
| 3. Touch ⚙ button for 3 seconds | The display shows the current height in (inch) format |
| 4. Release ⚙ button | The inches unit format setting is completed |

SET MAXIMUM HEIGHT

Maximum height setting ensures that the worktop cannot run above the preset height.



1. Lift and press the lever then release	Run the table to the position you want the worktop to be
2. Click  button for 6 times	The display shows “F01” function setting interface
3. Lift the lever or press the lever	The display shows “F03”
4. Touch  button for 3 seconds	The display shows “L”
5. Release  button	Maximum height is set

REMOVE MAXIMUM HEIGHT SETTING

1. Lift and press the lever then release	Run the table to any position
2. Click  button 6 times	The display shows “F01” function setting interface
3. Lift the lever or press the lever	The display shows “F04”/ “F06”
4. Touch  button for 3 seconds	The display shows “C”
5. Release  button	Maximum height setting is removed











SET MINIMUM HEIGHT

Minimum height setting ensures that the worktop cannot run below the preset height.

1. Lift and press the lever then release	Run the table to any position
2. Click  button for 6 times	The display shows “F01” function setting interface
3. Lift the lever or press the lever	The display shows “F05”
4. Touch  button for 3 seconds	The display shows “_L_”
5. Release  button	Minimum height is set

REMOVE MINIMUM HEIGHT SETTING

1. Lift and press the lever then release	Run the table to any position
2. Click  button for 6 times	The display shows “F01” function setting interface
3. Lift the lever or press the lever	The display shows “F04”/ “F06”
4. Touch  button for 3 seconds	The display shows “_C_”
5. Release  button	Minimum height setting is removed

VERIFY DIGITAL DISPLAY AND WORKTOP HEIGHT	
1. Lower worktop to the lowest position	Measure the table actual height and note the number in inches or in centimeters
2. Click  button 6 times	The display shows “F01” function setting interface
3. Lift the lever or press the lever	The display shows “F09”
4. Hold the  button for 3 seconds	The display shows “000”
5. Lift the lever or press the lever	Increase/Decrease the first digit to the corresponding first digit measured
6. Click  button	The second number starts flashing on the screen
7. Lift the lever or press the lever	Increase/Decrease the second digit to the corresponding first digit measured
8. Click  button	The third number starts flashing on the screen
9. Lift the lever or press the lever	Increase/Decrease the third digit to the corresponding first digit measured
10. Touch  button for 3 seconds	Completed
GYRO ANTI-COLLISION SENSITIVITY ADJUSTMENT	
1. Click  button 6 times	The display shows “F01” function setting interface
2. Lift the lever or press the lever	The display shows “F10”
3. Hold the  button for 3 seconds	The display shows “G-4”
4. Lift the lever or press the lever	Increases or decreases the sensitivity level. There are five levels of sensitivity: “G-0”, “G-1”, “G-2”, “G-3” and “G-4”. “G-4” indicates the highest sensitivity and “G-0” is no Gyro sensitivity.
5. Touch  button for 3 seconds	Completed
CORRECT THE GRAVITY REFERENCE	
Generally used for cases where the worktop is not level or cannot move up or down after installation.	
1. Click  button for 6 times	The display shows “F01” function setting interface
2. Lift the lever or press the lever	The display shows “F12”
2. Lift the lever or press the lever	Display current mounting position angle value Axx, release the  button. Completed.

ERROR CODES		
E01	Leg malfunction	1. Legs loose to the control box, check the cable connection, ensure the connection 2. Ensure cables are connected to the legs and control box
E03	Worktop overload	Weight overload - please reduce weight on worktop
E04	Control box malfunction	Under extreme weather conditions the control box may malfunction, please refer to initialisation procedure
E06	Communication disconnected	Disconnection between switch and control box
E12	Gyro error	ICC communication is malfunctioning, restart power